

**Portable Milli-Ohmmeter**  
**RESISTOMAT®**  
**Type 2323 (D07)**

© 2002 burster  
präzisionsmeßtechnik gmbh & co kg  
All rights reserved

Manufacturer:  
burster präzisionsmeßtechnik gmbh & co kg  
Talstraße 1 - 5 PO Box 1432  
76593 Gernsbach 76587 Gernsbach

**Note:**

The information contained in the following is subject to change without prior notice. No part of this document must be reproduced or processed using electronic systems without prior, written approval. burster does not provide any type of warranty for this device, including any implicit warranty concerning its general quality or suitability for a particular purpose. burster assumes no liability whatsoever for errors, incidental damage or consequential damage arising during the operation of this device.





## EG-Konformitätserklärung

Certificate of Conformity

Gemäß ISO/IEC Leitfaden 22 und EN 45014 erklärt  
According to ISO/IEC guidelines 22 and EN 45014 standard

Name des Herstellers: burster präzisionsmeßtechnik gmbh & co kg  
Manufacturer

Adresse des Herstellers: Talstr. 1-7.  
Address of the manufacturer 76593 Gernsbach

daß das Produkt  
Produktname: Mikroohmmeter  
Declares that the product with name RESISTOMAT®

Modellnummer(n) (Typ): 2323  
Model / Type

Produktoptionen: --  
Options

mit den folgenden Produktspezifikationen übereinstimmt  
is conform with following specifications of product

<b>Sicherheit:</b> Safety requirements	VDE 0100 Teil 410 Abs. 4.1+A2 (IEC 64) IEC 1010-1 EN 61010-03/94 VDE 0411 Teil 1	Schutzmaßnahmen; Schutz gegen gefährliche Körperströme Protection against electric shock Sicherheitsbestimmungen für elektrische Meß-, Steuer-, Regel- und Laborgeräte. Safety requirements for electrical equipment for measurement control and laboratory used
<b>EMC:</b> Electromagnetic	DIN EN 50081-1 VDE 0839 Teil 81-1	Elektromagnetische Verträglichkeit Fachgrundnorm Störaus- sendung Generic emission standard Part 1: Industrial environment Residential commercial and light industry
<b>compatibility</b>	DIN EN 50082-1 VDE 0839 Teil 82-1	Elektromagnetische Verträglichkeit Fachgrundnorm Störfestigkeit Generic immunity standard Part 1: Residential commercial and light industry
	CISPR 22 EN 55022 1987 VDE 0878 Teil 3 11/89	Grenzwerte und Meßverfahren für Funkstörungen von informa- tionstechnischen Einrichtungen Limits and methods of measurement of Radio Interference characteristics of Information Technology Equipment.

### Ergänzende Informationen :


Additional Information

Um optimale Störfestigkeit zu erreichen ist das Gerät über geschirmte Leitungen anzuschließen.  
In order to reach optimal electromagnetic immunity the device has to be connected with shielded line.

Gernsbach den 30.01.1996

Place / Date

Unterschrift des Herstellers  
oder Einführers  
Signature of manufacturer

  
i. V. Alfred Großmann  
(Leitung Qualitätswesen)  
Quality Manager



# CONTENTS

	Page
1. Safety	2
2. Introduction	4
3. Measuring Principle	4
4. Case Design	4
5. Maintenance	5
6. Battery Charging	6
7. Technical Data	7
8. Description of Controls	9
8.1 Measurement Current	10
9. Methods of Measurement	11
9.1 Ohmmeter Connections	11
10. Power-up	13
11. Measurement	13
12. Remote	14
13. Printer Output	15
14. Protection	16
15. Calibration Process	16
21. Calibration Reset	23

## IMPORTANT NOTE

Instruments are delivered ready for immediate use; no extras are required.

### Supplied Accessories:

- 1 Set of test leads
- 1 Mains cord
- 1 Operating Instructions (English)

When unpacked, inspect for physical damage and report any defects immediately in writing, retaining packaging materials for inspection. Before placing into service, ensure mains voltage is correct, instruments are normally supplied for 240V 50Hz. Other voltages may also be selected according to the chart in section 5, (Maintenance). Be sure to also change the fuse to the correct type.

### 1. SAFETY

This apparatus is designated Safety Class I as defined in the IEC Publication 348

This apparatus has been designed and tested in accordance with IEC Publication 348, entitled "Safety Requirements for Electronic Measuring Apparatus", and has been supplied in a safe condition. The present instruction manual contains some information and warnings which must be followed by the user to ensure safe operation and to retain the apparatus in safe condition.

If this apparatus is to be connected to a fixed installation, then before any other connection is made, the protective earth terminal must be connected to a protective conductor.

Before switching on the apparatus, make sure that it is set to the voltage of the power supply. The mains plug shall only be inserted in a socket outlet provided with protective earth contact. The protective action must not be negated by the use of an extension lead without a protective conductor.

### **WARNING!**

Any interruption of the protective conductor inside or outside the apparatus, or disconnection of the protective earth terminal is likely to make the apparatus dangerous. Intentional interruption is prohibited.

When the apparatus is connected to its mains supply, terminals may be live, and the opening of covers or removal of parts (except those to which access can be gained by hand) is likely to expose live parts.

The apparatus must be disconnected from all voltage sources before it is opened for any adjustment, replacement, maintenance or repair.

Any adjustment, maintenance and repair of the opened apparatus under voltage shall be avoided as far as possible, and, if inevitable, shall be carried out only by a skilled person who is aware of the hazard involved.

Make sure that only fuses with the required current rating and of the specified type are used for replacement. The use of makeshift fuses, and the short-circuiting of fuse holders is prohibited.

Whenever it is likely that the protection has been impaired, the apparatus shall be made inoperative and be secured against any unintended operation and returned to our factory or Agent for rectification.

## 2. INTRODUCTION

The DO7 is an accurate bench/portable Digital Ohmmeter for the measurement of resistance in the range  $0.1\mu\Omega$  to  $60\Omega$ . It offers you the four terminal resistance measurement method to eliminate the effect of lead resistance. The measured values are displayed on a 4-digit LCD display; an overflow of the selected range is also indicated.

### Display range 6000

Simple push-button selection of the range required, ensures that the DO7 may be easily used by unskilled personnel. Error and status warnings are illuminated when appropriate. The utmost care has been taken to ensure that the ohmmeter will withstand an accidental mains voltage applied to the measuring terminals, but it is not recommended that voltage should be applied.

## 3. MEASURING PRINCIPLE

The measurement is true 4 terminal, using the Kelvin principle. A stable current is produced across the resistance to be measured via the C terminals, and the voltage drop across the Rx is measured at the P terminals. This potential drop is then compared against the voltage drop across internal standards. The ratio of these is then converted to the resistance value of Rx and displayed in ohms on the digital display. High accuracy and long term stability is achieved by using our own manufactured internal resistance standards.

## 4. CASE DESIGN

The case is ruggedly constructed from an ABS/polycarbonate alloy, coloured safety yellow. A strong internal sub-frame ensures that the DO7 will withstand the harshest of environments. The front panel is a reverse printed polycarbonate overlay with clear and unambiguous text.



## 5. MAINTENANCE

Normally no maintenance is required other than cleaning with a moist cloth. Avoid aggressive detergents or solvents.

**CAUTION:** Before any maintenance, repair or exchange of parts or fuses, the instrument must be disconnected from the mains supply and all power sources. In the event of a fault occurring, the instrument should be returned to our factory or Agent. A mains fuse is fitted to the mains inlet socket on the front panel, and should be replaced if necessary.

**CAUTION:** Disconnect mains lead and all connecting leads, before removing fuse holder. Replace only with the correct fuse type, ie. according to the following chart.

Line Voltage Selection	Range VAC 47-63Hz	Fuse (250V) IEC 127 5 x 20 mm.
100V 120V	87-110V 104-132V	2.5A (T)
220V 240V	191-242V 209-264V	1.25A (T)
Maximum Input Power : 80VA		

The input circuits are protected by a 6 AMP fuse located in a holder on the main printed circuit board. Access is gained by removing the top cover. Only replace with the correct fuse type as below.

10A 550V rms Type A1

BS 88 : PART 2 

## 6. BATTERY CHARGING

The DO7 has built-in rechargeable sealed lead acid batteries which are fully charged when delivered. To ensure good service life from the batteries, the DO7 incorporates a sophisticated battery management system. To indicate the state of charge, 8 LEDs indicate the remaining battery capacity in % of full charge. These LEDs are arranged in a gas gauge style.

The battery charger is built in and the instrument may be connected to 100/120/220 or 240 volts supply. The appropriate voltage setting must be selected on the inlet socket and the correct fuse inserted. The LINE LED will illuminate on the front panel to indicate when the mains supply is connected.

Charging is automatically controlled with built-in protection circuits eliminating the possibility of over-charging. The display will blank when the battery voltage is too low to sustain measurements, and the battery state indicators show the current state of charge. The DO7 will operate whilst charging on all ranges except the bottom two, and an additional error of approximately 8 digits may be observed with mains supply connected. The lower ranges have a larger measuring current than can be supplied by the charger, and therefore batteries must be fully recharged before use. The batteries will recharge in approximately six hours, and the DO7 lid should be open to allow for maximum ventilation.

### Batteries

The internal batteries are a sealed lead acid type. Care should be taken when disposing of them and they may be returned to Cropico for safe disposal.

Any regulations and directions applying to the disposal of such material must be applied.

Do not dispose of battery in fire.

Do not short circuit.

Do not crush, puncture, open, dismantle or otherwise mechanically interfere with the battery.

### TECHNICAL DATA

Digital Display :	4 digit, LCD 0.8" height; 6000 count with automatic decimal point and error warning lamps
Working temperature :	0...+40°C rel. humidity max. 80%
Normal temperature :	20°C
Storage temperature :	-20°C ... +50°C
Mains connection :	100/120/220/240V +10 -13% 47-63 Hz
Size (mm.) :	343 x 327 x 152
Mass :	8.3 Kgs.

## Measurement

Resistance	:	True four-terminal measurement with fixed dc measuring currents.
Measuring time	:	Approx. 0.5 seconds
Polarity	:	Forward and reverse measurement current may be selected, plus average mode which automatically displays the average value of positive and negative polarity measurement.

## Ranges and Accuracy

Range	Resolution	Typical Current	Uncertainty At 20°C ±5°C, 1 Year	Temperature Co-efficient/°C*
60 Ω	10m Ω	1mA	±(0.25%Rdg + 0.02%FS)	25 ppm Rdg + 2 ppm FS
6 Ω	1m Ω	100mA	±(0.25%Rdg + 0.03%FS)	25 ppm Rdg + 10 ppm FS
600m Ω	100μ Ω	100mA	±(0.25%Rdg + 0.1%FS)	25 ppm Rdg + 90 ppm FS
60m Ω	10μ Ω	1 Amp	±(0.25%Rdg + 0.1%FS)	25 ppm Rdg + 90 ppm FS
6m Ω	1μ Ω	10 Amp	±(0.25%Rdg + 0.1%FS)	25 ppm Rdg + 90 ppm FS
600μ Ω	0.1μ Ω	10 Amp	±(0.25%Rdg + 0.1%FS)	25 ppm Rdg + 90 ppm FS

\* NOTE Temperature coefficient to be added to uncertainty when operating outside the range 15 to 25°C

NOTE: Measurements on the lowest range 600μΩ will have an additional zero offset of up to 20 digits, if the measuring current is applied for long periods. This offset can be eliminated by using the average measuring mode.

## 8. DESCRIPTION OF CONTROLS




Fig. 8-1 Description of Controls

## 8.1 Measurement Current:

The measuring current polarity may be selected from the front panel. The display will indicate either + or - to denote the current flow. This is particularly useful when evaluating circuits with thermal emf or where diode effects can influence the measurement. For measurements where thermal emf can cause a large measuring zero error, we have provided an additional automatic average button. When pressed, the measuring current will automatically be reversed and the average value displayed, thus eliminating the need for external computations. This average facility will also adjust the measurement time automatically, thus giving the fastest possible measurement even on inductive circuits.

The +ve and -ve lamps will light to indicate that the current polarity is changing. For very unstable values where the average mode is unable to establish a stable reading, the averaging will be aborted after approximately 25 seconds and the display will indicate - - - - A new average cycle will be automatically initialised.

## Range Selection:

The 6 ranges may be selected manually by simply pressing the desired range button. The selected range will be indicated by an LED and over-range will be indicated by the display reading - - - -.

## Error & Status Lamps

These LEDs will light to indicate the instrument status..

- LINE : Mains supply is connected to the instrument.
- CAL : Calibration mode has been initialised by the key switch and the instrument is in calibration mode.

O/C  
LEAD : One of the measuring leads is open circuit (too high resistance), or not connected to test sample correctly, or the internal protection fuse is open circuit. The lamp will always light in standby mode.

## 9. METHODS OF MEASUREMENT

### 9.1 Ohmmeter Connections

The Digital Ohmmeter type DO7 employs a four wire method of measurement, ie. it is necessary to make four connections to the resistor under test. The instrument is supplied with four leads; two for the potential connections which are made across the test resistor at the points between which the resistance is to be determined; and two for the current connections which connects the test resistor to the supply circuit.

- a) Connect the black leads to the C1 and P1 terminals, and the red leads to terminals C2 and P2.
- b) Clip on to the resistor under test (fig. 9-1). Cleanliness is important and if the sample is not clean, a rub with an abrasive paper to remove oxides is recommended.
- c) It is not always possible to use the combined current and potential clips, in which case test leads with spade tags or special test fixtures may have to be made for the user to suit particular applications.
- d) Fig. 9-2 illustrates connections to various types of test resistors.
- e) When measuring 4-terminal resistance standards, do not use the combined current and potential probes. Make four separate connections to the current and potential terminals




Fig. 9.1 Combined current and potential probes




Fig. 9.2 Various types of resistors



## 10. POWER UP

When the DO7 is first switched on, a lamp test is automatically performed. All display segments are illuminated followed by each LED lighting in sequence. *NOTE* the LOCK LED is not fitted and will therefore will NOT light. The microprocessor checks for correct internal operation and indicates "P" if all tests pass O.K. At the same time the software version will be displayed and held for approximately 2 seconds. The display will typically read "P 1.1". Should the internal checks indicate an error, then the display will read "HELP". To rectify this, see section 13.

The DO7 will perform an automatic zero sequence and finally sets to the following default start-up mode ready for use. The selected measuring range will be  $60\Omega$ , and the DO7 will then be in stand-by mode.

## 11. MEASUREMENT

Connect the resistance to be measured ( $R_x$ ) to the measuring terminals in accordance with the diagram on the instrument panel. Select the range required, the measurement mode, ie. +, - or average. The LED lamp will light to indicate which buttons are active. To initialise the measurement, press and hold the ON button, the measurement will cease once this button is released and the instrument will return to the STANDBY state. Should you wish to initialise a continuous reading, then press the LOCK + ON buttons. The measurement will continue until the STANDBY button is pressed or the ON button pressed again. An audible BLEEP will sound during this time to warn the operator that measurement is still in progress, and up to 10 Amps measuring current is draining the batteries.

### Over-Range

The display will indicate - - - -.  
Select a lower range.

### Open Circuit Lead

O/C LEAD will be displayed and the display will indicate - - - - if the instrument detects that the lead resistance is too high. The C terminals are checked for compliance voltage. Measurement should not be made if this warning message is displayed. This warning will also be displayed if the internal protection fuse is open-circuit. When in STANDBY mode this LED will always be lit.

### Connections

When making good quality measurements, it is important to ensure that all measuring leads are in good condition, and less than 0.2 ohms resistance.

It should also be noted that some spade tags and crocodile clips can produce high thermal emfs when warmed, particularly nickel-plated brass types. This can cause problems when, for example, connecting too hot motor windings. The solution is to use plain copper or brass connections keeping them clean and oxide-free.

## 12. REMOTE

If a footswitch or other similar external switch is plugged into the REMOTE socket, it will behave as an ON key. This feature is particularly useful when used with the PRINT LAST function to enable "hands free" operation during measurement, with the results printed on an external printer. For switch connections see page 27.

### 13. PRINTER OUTPUT

The print format will be as follows:

SIGN	VALUE	UNIT (measuring mode)
------	-------	-----------------------

example:	+600.0 m ohm (+ve)	
	-600.0 m ohm (-ve)	
	600.0 m ohm (Ave)	

The value printed will be followed by a line feed carriage return.

Should the instrument display read over-range then the value will be printed as

----

For cable connection details see page 27.

#### Print All

All measured values will be sent to the printer port (RS232) when "ON". This key toggles ON/OFF.

#### Print Last

The last measured value only will be sent to the printer port (RS232). This is defined as the last value measured when switching from "ON" to "STBY". This key toggles ON/OFF.

#### Baud Rate

This key will display the currently set value when pressed. To change the value, press CLE to clear and then use the keyboard to enter the new value, finishing with OK. If the new entered value is a valid rate, then it will be stored and retained in the NVRAM. If it is invalid a long bleep will sound and it will reset to the last value. The valid Baud Rates are: 75, 110, 150, 300, 600, 1200, 2400, 4800, 9600, 19200. The format is fixed at 8-bit data, 1 start bit, 1 stop bit and no parity.

## 14 PROTECTION

Every effort has been made to protect the instrument against voltages being applied to the terminals. A large 6 Amp fuse is fitted internally to the C measuring line and a gas discharge tube, GDT, is across the C terminals. If voltages above approximately 90V are applied to the measuring terminals, the GDT will strike, effectively shorting the C terminals through the 6 Amp protective fuse, which will interrupt the circuit.

The fuse fitted will interrupt up to 40,000 Amps. The P terminals are not fused and will withstand up to 460 Volts without damage to the instrument.

### **WARNING !**

To replace the protection fuse, the top instrument panel should be removed, *but only after the mains supply and all input connections are removed.* The protection fuse is located on the main printed circuit board. Only replace with the correct fuse rating.

## 15. CALIBRATION PROCESS

This procedure describes the standard calibration method for the DO7 Ohmmeter using Cropico Calibration Rig Type MTS2. If discrete resistance standards are to be used instead, refer to section 21 before proceeding.

If the calibration stores are to be pre-set or erased, use the special operation described in section 6 (CAL RESET).

### CAUTION

The DO7 will be factory-calibrated to its full accuracy when delivered and any recalibration by the user will invalidate this initial calibration. The user should therefore be certain that only authorised and competent personnel are permitted access to the calibration facility, which is key protected. .


16. **EQUIPMENT REQUIRED**

Cropico Calibration Rig Type MTS2  
Set of 2 low thermal emf leads  
Set of 2 general purpose leads (10A rating)  
Calibration key no. 901

17. **PREPARATION**

17.1 Ensure all retaining screws are fitted.

17.2 Connect each of the four DO7 terminals to the equivalent terminals on the calibration rig. It is essential that low thermal emf leads are used for the P1 and P2 leads (see Fig.17.1 for the preferred setup).



P1, P2 LEADS - PURE COPPER, MULTI STRANDED  
C1, C2 LEADS - 10A RATING (55/0.15mm)

17.3 The DO7 is powered by internal batteries and these should be fully charged before carrying out calibration. The mains charger can be left connected, if desired.

17.4 Set the calibration rig to 40 Ohm, Zero.

17.5 Turn the DO7 power ON. If the "HELP" message is displayed, carry out the CAL RESET operation of section 6 before continuing.

17.6 Leave for a few minutes to stabilise.

## 18. CALIBRATION

18.1 Insert the calibration key into the panel switch and turn to CAL. The CAL LED should light up.

18.2 Set the calibration rig to 40 Ohm, Zero.

18.3 Set the DO7 to 60 Ohm range, +ve, and press LOCK+ON.

18.4 When the reading has settled, press KYB. The display should read 0.

Press OK. The LED should light up for about 3 sec.

The reading should now be 0.00 +/-1 digit. If not, repeat this step.

18.5 Set the calibration rig to +FS.

18.6 When the reading has settled, press KYB.

Enter the value 40 using the keypad and press OK. The LED should light up for about 3 sec.

The reading should now be 40.00 +/-1 digit. If not, repeat this step.

18.7 Repeat steps 18.2 thru' 18.6 for the remaining ranges.

18.8 Turn the panel switch to RUN and remove the key.

19. VERIFICATION

19.1 Ensure that the panel switch is set to RUN and the calibration key is removed.

19.2 Set the calibration rig to 40 Ohm, Zero.

19.3 Set the DO7 to 60 Ohm range, +ve, and press LOCK+ON. Wait for the reading to settle.

The reading should be 0.00 +/-1 digit. Note the actual reading in the Calibration Test Results sheet.

19.4 Set the calibration rig to +FS and wait for the reading to settle.

The reading should be 40.00 +/-1 digit. Note the actual reading in the Calibration Test Results sheet.

19.5 Set the DO7 to -ve and wait for the reading to settle.

The reading should be -40.00 +/-1 digit. Note the actual reading in the Calibration Test Results sheet.

19.6 Set the DO7 to AVE and wait for the reading to settle.

The reading should be 40.00 +/-1 digit. Note the actual reading in the Calibration Test Results sheet.

19.7 Reset the DO7 to +ve. Set the calibration rig to 4 Ohm, 2+FS and wait for the reading to settle.

The reading should be 4.00 +/-1 digit. Note the actual reading in the Calibration Test Results sheet.

19.8 Set the calibration rig to 400m Ohm, +FS and wait for the reading to settle.

The reading should be 0.40 +/-1 digit. Note the actual reading in the Calibration Test Results sheet.

19.9 Set the calibration rig to 40m Ohm, +FS and wait for the reading to settle.

The reading should be 0.04 +/-1 digit. Note the actual reading in the Calibration Test Results sheet.

19.10 Repeat steps 5.2 thru' 5.6 for the remaining ranges.

19.11 Turn the DO7 power OFF and remove the test leads.

19.12 Affix a calibration seal label to the instrument.

19.13 Sign and date the Calibration Test Results sheet.

***\*\* END OF NORMAL CALIBRATION PROCEDURE \*\****



20. USING DISCRETE RESISTANCE STANDARDS

20.1 Discrete, 4-terminal resistance standards may be used in place of the Cropico Calibration Rig. The standards must have an uncertainty better than 0.01% if the full calibration accuracy is to be achieved. Full consideration of the DO7 measuring current must also be taken into account when selecting the standards. The DO7 can be calibrated to standards between 1000 and 6000 digits for each range using the KYB entry. However, full accuracy will only be achieved if standards of 4000 to 6000 digits are used. The following nominal standards are recommended:


40, 4, 400m, 40m, 4m and 400u Ohm

20.2 In all measurements the P1 and P2 terminals are conventionally connected. Bear in mind that thermal emfs may be present. The DO7 is particularly sensitive to these on the 600u Ohm range.

20.3 For FS measurements, connect the C1 and C2 leads in the conventional manner (see Fig 20.1).

20.4 For ZERO measurements, connect the C1 and C2 leads to the C2 terminal of the standard (see Fig 20.2).


FULL SCALE CALIBRATION



P1, P2 LEADS - PURE COPPER, MULTI STRANDED  
C1, C2 LEADS - 10A RATING (55/0.15mm)

Fig. 20.1

ZERO CALIBRATION




P1, P2 LEADS - PURE COPPER, MULTI STRANDED  
C1, C2 LEADS - 10A RATING (55/0.15mm)

Fig. 20.2

**\*\* END OF TEST PROCEDURE \*\***

21.        **SPECIAL OPERATION - CAL RESET**

- 21.1        This part of the procedure is used to pre-set the calibration memory to a default condition. It will erase all previous calibration data. With Ver 1.X software, this feature can only be used if a calibration memory failure has been detected. This test is performed at power-up and failure is indicated by the HELP message.
- 21.2        Turn the DO7 power ON. Wait for the display test to complete and the HELP message to appear.
- 21.3        Insert the calibration key into the panel switch and turn to CAL. The CAL LED on the front panel should light up.
- 21.4        Press CLE. The LED should light up for about 1 sec.
- 21.5        The HELP message should now be replaced by the normal display.
- 21.6        Turn the panel switch to RUN and remove the key.



## REMOTE START

